


















Stand Assembly Kit

	A - Metal Pivot Bridge	x1
	B - Metal Pivot Bush	x2
	C - Metal Pivot Washer	x2
	D - Nylon Pivot Spacer	x2
	E - Nylon Pivot Pad	x1
	F - Metal Pivot Axle	x1
	G - M8 x 35mm Bolt	x2
	H - M8 x 20mm Bolt	x4

TV Fixing Kit

	I - M6 x 25mm	x4
	J - M8 x 16mm	x4
	K - M8 x 25mm	x4
	L - M6 washer	x4
	M - M8 washer	x4
	N - M8 x 6mm	x4
	O - M8 x 12.5mm	x4
	P - M6 x 20mm	x2

Extender fixings

	H - M8 x Nut/Washer	x16
--	---------------------	-----

pmvmounts.co.uk


Mounting instructions for XL Universal TV desk/table top stand.
VESA 200/300/400/600 x 400 - Universal up to 800mm X 500mm
37" to 75" - Up to 75Kgs

Model No.
PMVMOUNTMTDX

Factory No.
ZMTD5


- Read these instructions carefully before installing your equipment.
- Install the stand in a suitable location and only on a horizontal flat surface.
- Do not attempt to alter or modify any part of the desk mount or its attachments.
- Do not use if any parts are broken or appear to be damaged.
- Tighten all bolts and fixings securely. Only use fixings provided with this stand.
- Do not mount your TV close to sources of heat or moisture.
- Always have a minimum of two persons to install the TV.

1 Assemble Stand





2

Attach TV Mounting Plate.




3

Attach Screen Fixing Uprights To Screen




4

Hang Screen On TV Mounting Plate




5


Using Extender Plates



a
Top width extender x2




b
Bottom width extender x2



c
Height extender x2

Configuration with
Height and Width
Extenders



Configuration with
Width Extenders only

